

Corsair Utility Engine Software

Updated Release

Version 1.7.106

June 1st, 2015

Corsair Vengeance K70 RGB keyboard	Windows 8/8.1
Corsair Gaming K65 RGB keyboard	Windows 7
Corsair Gaming K70 RGB keyboard	
Corsair Gaming K95 RGB keyboard	
Corsair Gaming M65 RGB mouse	
Corsair Gaming Saber RGB mouse	
Corsair Gaming STRAFE	

Release Notes

CUE 1.7.106 is the latest release for our RGB line of peripherals and contains a multitude of changes and enhancements.

Enhancements

- CUE Link is a new enhancement that allows for lighting patterns to extend from a Corsair RGB keyboard to other Corsair RGB peripherals such as Sabre and M65 RGB. Simple lighting patterns such as pulse and shift will allow for simultaneous color change between devices whereas multiple color patterns like Rainbow Wave will start from the keyboard and end at the mouse. (Note: This feature does require a combination of Corsair RGB peripherals)
- CUE now supports the Corsair Gaming STRAFE keyboard, the newest addition to our peripheral line-up. For more information, please visit <http://www.corsair.com/en/landing/strafe> .
- CUE GUI now uses the new Corsair Gaming Logo.

Fixes

- Sniper light indicator is now properly lit red.
- Resolved issue with Macro Repeat speed at 1ms.
- Brightness setting at 0 properly displays no color (Off).
- Resolved other various minor issues.

Important Note:

If you have updated your keyboard to FW 1.20 or newer, software older than 1.5.108 will no longer be compatible.

Please ensure you always have the latest software available when updating the firmware to prevent incompatibility.

Firmware updates are done through the software itself under Settings -> Device -> Update Firmware.

Keyboard Connectivity:

- Connecting via USB 3.0: Use one connector (the one with the keyboard icon) when connecting via USB 3.0
- Connecting via USB 2.0: Use both connectors when using USB 2.0. Important Note: Plug in the connector with the two arrows icon first, and the connector with the keyboard icon second.